

# (1/2) Specification Sheet

## 3500W lithium battery charger

〈 Industrial / Indoor / Stationary 〉

Applications: Automation systems (FA) / Industrial electric vehicles / Autonomous robots (AGV / AMR)

Applicable batteries: All types of batteries that fit the charging voltage range, including lithium batteries (ion, polymer, iron phosphate)

\* See separate document for communication protocol (RS485) [2 of 2, Communication protocol]

### Model: TC-3500W-50V60A

For 50V battery : Charging voltage 52V~Max. 58V, charging current 10A~60A / Charging current (5A unit), voltage (0.5V unit) adjustable type

 **It is set to 57.0V, 40A at the factory.**

Input power: Single-phase AC200V ~240V/18A at 220VAC

We do not provide AC input wires, you will need to provide your own.

Do not use a pig-nose outlet plug due to the excessive AC input current (up to 18A) of this device.



front

back



2D drawings (DWG), 3D drawings (STP, IGS), communication protocols (protocol\_ RS485), specifications, user manuals (user manuals), etc.

You can download it from the Tabos homepage.

Designed and Made by TABOS in Korea / Export HS Code : 8504.40.30

---




## Table of Contents




1. product mix and customer ready items
  2. Important notes
  3. list of specifications
  4. drawings
  5. product features/safety features
  6. how to use
  
  7. settings and external control methods
    - 7-1. External Control Using DIO
    - 7-2. Control by connectig to the control panel (option product) using DIO
    - 7-3. External Control via RS485 Communication / Using D-SUB 9Pin Connector
  
  8. Error and status messages
    11. Add an external control method
      - 11-1. Blue Tooth Wireless Communication
      - 11-2. Ethernet (LAN) Communication
  
  21. Charger Control Panel (optional) specifications/drawings and usage
- 





◆ **Special Notes: CE and CB Certification Conditions:**





- 1) User Interface / Operational testing of communication ports (D-SUB 9-pin, DIO port) excluded.
- 2) User Interface / Operational testing of communication ports for parallel operation excluded.
- 3) User Interface / Operational testing of Thermal S/W input terminals excluded."


## 1. product mix and customer ready items

Default/O ptional	Item	Photos	Name	Specs	Remarks, uses
Products for sale (default)	Charger body		TC-3500W-50V60A		
Products for sale (default)	Output wire (charging wire)		m6-25sq-1m-rb-m6	(1) Wire KIV 25sqmm (Red (+) and Black (-)) (2) Wire length of 1 meter (3) Double-ended ring terminal (M6) Crimp terminals: Jor / JOR25-6 and similar	
Products for sale (Optional)	Anderson connector wires		SB120A-Gray-M6-800L	Connector: Anderson SB120A, Gray Ring terminal: opposite the connector, ring terminal for M6 Wires: KIV, 25 mm <sup>2</sup> , red+black, Length: 800 mm (excluding connector body dimensions) <hr/> Notes : 2 required (one for the battery, one for the charger)	Sold separately  (For safety management/conv enience)

Default/O ptional	Item	Photos	Name	Specs	Remarks, uses
Products for sale (Optional)	Charger Control Panel		TWC-TX-STA-PNL	(from left in photo) *Charge status indicator→ Standby (Y), Charging (G), Error (R) *Emergency switch *Charge ON/OFF switch (rotary switch) *Error clear switch (pushbutton) ----- * Ability to drive additional external FANs while charging * Ability to detect whether the robot (AGV, AMR) has arrived at the charging station and access the proximity switch.	Sold separately  (For safety management/conv enience)
Products for sale (Optional)	DIO communication lines		trx-dio-cable-2.0m	(Cycle: Auto detects battery connection and charges automatically when set to Auto mode without this DIO). ----- *Connector housing : *Mollex 430250800  *Wire : UL2464, 8Core shielded cable *Wire length is 2 meters, *Pin number 1,2,3,4,5,6,7,8 / *Color: (in pin order) Black, Red, Orange, Yellow, Blue, Green, Brown, White	Sold separately  (Prepare as needed)  Only required when communicating with DIO
〈 hereafter prepared by the customer 〉.					

Default/O ptional	Item	Photos	Name	Specs	Remarks, uses
(Prepared by customer )	AC input wires		< cycle >.  (Don't use pig-nose formatting)  *Reason : Exceeded pig nose usage with input current 18A  *Bite directly into the blocker.	(1) Wire VCTF (or VCT) 3 Core ( L, N, E ) , 4 mm2  (2) Connection ring terminal: Use the ring terminal for M4, Crimping Terminal Recommendation : JOR4-4 / JOR5-4  (3) Recommended wire stripping length = 50mm  (4) AC220V : L, N, E→ 3-wire	Essential basic preparation
(Prepared by customer )	European industrial socket plug  (Legrand plug/socket)	 		Type : Socket (female) : 555214 Type : Plug (Number) : 555234 ----- European industrial sockets/plugs AC250V 32A ----- < cycle >. Something handy to put between the charger and the breaker.	(Prepare as needed)  (handy to have)
(Prepared by customer )	Wires for grounding			(1) Wire KIV, Green, 1 Core, 4 mm2  (2) Connection ring terminal: Use ring terminal for M4 Crimping Terminal Recommendation : JOR4-4 / JOR5-4	Essential basic preparation

Default/O ptional	Item	Photos	Name	Specs	Remarks, uses
(Prepared by customer )	D-SU9-pin connector cable for communications		D-SUB 9-pin cable Supin (Male)	(Cycle: Auto detects battery connection and charges automatically when set to Auto mode without this DIO). ----- Compared to communicating using DIO 1) You can command the charge voltage and charge current size to change ON Line. 2) You can get detailed data about the error.	(Prepare as needed)  Only required when communicating over RS485
(Prepared by customer )	Parallelism Communication cables RJ45		rj45 ( 8p8c / cat6 ) , Total Length = 200mm Fit ,  CAT6 and higher numbers are fine. (e.g. CAT7, CAT8, CAT9 )	Quantity required : 2Parallel operation→ 1 3Parallel operation→ 2 4Parallel operation→ 3 	(Prepare as needed)  You may want to run multiple chargers in parallel to increase the output. Required only if
(Prepared by customer )	RS485 to Blue Tooth Wireless Communication Converters  ----- ( Serial to Bluetooth Converter )		Connecting to this charger: Name1 : RCPORT-TD450 / ( Male / Male ) ----- Connect to Host Name2 : RCPORT-TD420 / ( USB plug )	Plug this directly into the Tabos charger D- SUB 9-pin connector (female, female). The pin map matches. 5V power is also supplied directly from the D-SUB 9-pin. Manufacturing, sales: Chipsen / chipsen.com I put the considerations behind the documentation I created in Tabos.	(Prepare as needed)  Monitor / control the charger via Bluetooth wireless communication When you use

Default/O ptional	Item	Photos	Name	Specs	Remarks, uses
(Prepared by customer )	RS485 to Ethernet (LAN) communication Converters  ----- ( Serial to Ethernet Converter )		Type: sLAN/all	Caution: You cannot plug this directly into the Tabos charger D-SUB 9-pin connector (female, Female), the pinmaps do not match. You will need to make your own pin-matching wire harness and insert it between the Ethernet converter and the D-SUB 9-pin connector of the Tabos charger. Manufacturing, sales: System Base / sysbas.com Special considerations for applying to the Tabos charger have been included after the documentation created by Tabos.	(Prepare as needed)  Monitor / control the charger with Ethernet (LAN) communication When you use



## 2. Important Cautions (Designers & Users)


**⚠ Charger Enable Switch**→ This unit will only operate when this connector is shorted (Closed , Shorted).

If the LCD window is off even though the charger's main switch is turned on, click the

This is because this 'enable switch' is open.

**Before use, make sure that the electrodes of this connector are shorted to each other. They must be shorted to work. Normal Closed.**

(The 'enable switch' is short-circuited with jumper wires at the factory by Tabos. )



타보스 공장출하시  
합선(점퍼선) 상태임.



Enable  
Switch



스위치 회로의 전류 : 100mA 이하.  
비상스위치를 달아서 사용하면 좋음



In the 'Enable Switch( **N.C. Type** )', you can put an emergency switch to make it easier to react in case of an emergency.

What is Emergency?→ It is useful in case of fire or smoke in the battery and related circuitry while charging.

If you open (off) this 'Enable Switch' while charging (i.e. press the emergency switch), it will stop charging immediately.

Even if this behavior occurs frequently, this charger will not be overwhelmed.

When the Enable Switch is in the Open (Off) state, the LCD window displays the message below.

Enable S/W off Status.  
Check Out Enable S/W



 The charger has two modes of operation and is set to "Auto" at the Tabos factory.

#### A) Automatic Mode

When a battery is connected, the charger automatically detects its voltage and charges it if it's okay.

Shut off the output of the charger when the battery is disconnected from the charger.

This means that the output of the charger will not be energized unless the battery is plugged in.  
 (Safety Management Dimension)

#### B) Manual Mode

You can manually turn the charge on/off with the buttons on the LCD monitor, or use the


Use the communication cable to control the charge (via RS485 or DIO command).

Again, just like in automatic mode, the

It only outputs electricity when the battery is plugged into the charger.


This means that the output of the charger will not be energized unless the battery is plugged in.  
 (Safety Management Dimension)

You can change the mode via the 'Auto/Manual' button pictured below, and you can also use the  
 Once changed, the mode is remembered even when powered off.



MAN / AUTO information is also displayed on the LCD monitor.

In manual mode, you can press the 'CHG ON/OFF' button under the LCD monitor or give a charge command via communication (RS485 or DIO).

 **Battery charging Do not turn AC input power on/off for the purpose of turning on/off the charging behavior.**

(If used in this way, the charger's firmware (S/W) may malfunction in some cases, resulting in impaired operation.)

This charger detects the battery connection status (battery present or absent) and automatically controls charging. It is safe because the output does not go out when the battery is not connected. It works automatically even if the AC input power is not turned on or off.

When applied to automated guided vehicle (AGV) charging stations, always keep the AC input power ON and apply the charging electrodes to the AGV upon arrival at the charging station to automatically initiate charging.

 **Charging a lithium battery with an undervoltage cutoff would not charge properly.**

If the lithium battery is undervoltage cut off, and the standby power of the load connected to the charger (which also has the battery connected) absorbs the charger's startup current, the battery may not be able to charge and remain in standby.


This situation can occur in automated guided vehicles (AGVs), driving robots, etc.

The charger has a failsafe that prevents the output from going out when no battery is connected.

Lithium batteries have a built-in BMS/PCM device that will shut down the output if it goes into a low voltage state. The charger will detect if the battery is connected by the micro output, and if the battery is in a low voltage cutoff state, it will not detect the battery voltage, so it will not do a full charge and will only send out micro power.

If the various electrical devices connected to the load are left on, the trace power from the charger will be consumed by the load's standby power, preventing it from charging over time.

If this happens, you should turn off the switch (breaker, etc.) that is connected to the load so that the charger's small output current does not drain the load's standby power. After doing so, you can turn on the switch that is connected to the load once the charger has started charging.

 **The use of wires that are too thin for the current will cause the wires and connectors to deteriorate in the long run, resulting in fires.**

For charging wires, you should also use the proper wire thickness to reduce the amount of voltage drop to ensure that charging is on target.

The wire thickness is determined by the current draw.

#### AC input power wire:

**Formula for calculating the allowable current per wire diameter for AC input wires:  $5A/mm^2$  minimum<sup>2</sup> (SQMM).**

In a normal temperature environment, the allowable current per 1 mm<sup>2</sup> (square millimeter) of wire can be calculated as 5 amps. If the ambient temperature is above 40 degrees Celsius, you may also need to use thicker wire than the above calculation, but this is for safety reasons, such as the wire heating up.

If the maximum current of the AC input is 20A --> Minimum  $20/5 = 4$  mm standard wire<sup>2</sup> Wire selection.

**DC battery charging wire:**

**Formula for calculating the allowable current per wire thickness of the charging line: minimum 3A/mm<sup>2</sup> (SQMM). (Condition: when the length of the charging line is 2 meters or less.)**

This is the specification recommended by Tapos. Thin charging wires cause a voltage drop. Even a voltage drop of 0.5 V will cause the battery to charge less. This is to reduce the amount of voltage drop across the wires when charging to ensure that the charging is on target.

If the length of the charging wire is longer than 2-3 meters, you should use a thicker wire than the above calculation because there is a large voltage drop during charging. If the ambient temperature is above 40 degrees, you may also need to use a thicker wire than the above calculation.

If the charging current is 60A --> at least  $60 / 3 =$  at least 20 mm<sup>2</sup> --> standard wire 25 mm<sup>2</sup> Select the wire.

The use of wires that are too thin for the current will cause the wires and connectors to deteriorate in the long run, resulting in fires.



Set the charge current setting lower than the allowable charge current of the battery you are charging.


Set the charge voltage setting to lower than the allowable charge voltage of the battery you are charging.

### 3. list of specifications

Tabos Development / Direct Production ( Made in Korea )

No	Item		Model Name : TC-3500W-50V60A	Remarks
1	Certification		CE ( TUV ) , FCC , CB ( TUV ) : Certif. No. : DE3-HS00641  Applied Standards : IEC 60335-1,2 , IEC 61000-6, Class A	
2	Applied Battery	Li-ion and Iron phosphate batteries	For charging batteries with a nominal voltage of 48V to 52V. Used to adjust the maximum charging voltage.	The customer's maximum battery charge voltage specification Set the maximum charge voltage on the LCD window.
3	DC charging voltage	Maximum battery voltage at full charge	<b>52.0 VDC to 58.0 VDC</b> (Charging voltage can be adjusted in 0. 5 V increments on the LCD display)	<b>Factory-set charging voltage = 57V</b> (Users adjust the charging voltage to suit their situation.)
4	DC Charge Current	Current adjustable, Charge Current Ripple Reduction	<b>10A to Max. 60A</b> , (3% or less charge current ripple) (Charging current can be adjusted in 5A increments on the LCD display)	<b>Factory-set charging current = 40A</b> (The user adjusts the charging current to suit the situation.)
5	Parallelism features	Run up to four in parallel (Master / Slave)	Parallel operation of up to 4 units Output DC 60A * 4 parallel = increase to output DC 240A	
6	DC charging power		<b>Up to 3,480 W</b> ( = 58 V * 60 A )	
7	Battery charge	Battery charge at full charge	<b>Approximately 94</b> (Results from limiting the charging voltage to 58V Max for safety)	
8	DC End-of-Charge Current	View as full and end charge (about 10% of the charging current)	Approx. 5 A	


No	Item		Model Name : TC-3500W-50V60A	Remarks
9	Recharge start voltage	If the charger has a battery in the	The battery remains plugged into the charger and charges to a full charge before shutting down. After that, if the voltage drops, it will start charging again, and the resumption voltage is called the resumption voltage.	
			* Recharge voltage = the set maximum charge voltage (set by the user in the LCD window) (-) 2V lower. Example) If you set the maximum charge voltage to 56V, recharge will work at 54.	
10	DC charging wire thickness	Room temperature guidelines	25 mm2 ( = 60A/ (3A/mm2) or more) / KIV wire	
11	Charging methods		Constant Current/Constant Voltage, CC/CV (Constant Current/ Constant Voltage), Slow Start (Gradual increase in current after charging starts)	
12	Charger format	Isolated	Isolated charger with transformer-isolated primary (AC power supply) and secondary (DC charging) sides (A feature that prevents an internal failure of the charger from causing primary power to go directly to the battery.)	
13	AC Input Voltage	RMS value	Single-phase 200 VAC to 240 VAC / 50 to 60 Hz	When using a reduced battery charge current value, the AC input current can be calculated as a percentage of the charge current. (Calculation example) : If 40A is charged, AC input current is (40A/60A)*18A=12A
14	AC Input Power, Current	RMS value	Approx. 4,000 VA, 18 A (AC220 V, battery charge 60 A)	
14-1	Leakage Current	AC Input Line	Under 2 ~ 2.5mA , Ref. : According to the KC/IEC/EN 60335-1/-2-29 standard for this charger, the allowable leakage current is Max. 3.5mA or less.	
14-2	AC Input Terminal Screw	SEMS, (+) Head : M4-10	Fastening torque (tightening torque): 12 (kgf*cm)	
15	Power switch	(Power switch located next to the LCD window on this charger)	20A breaker (thermal_time-delayed) equipped.	

No	Item		Model Name : TC-3500W-50V60A	Remarks
16	AC incoming wire ( bold, ringterminal )		<p>(1) Wire color VCTF (or VCT) 3 Core, 4 mm<sup>2</sup> ( = 18A/ (5A/mm<sup>2</sup>) or higher) * Cycle: Safe wire allowable current is 5A/SQMM, max 7A/SQMM (2) Connection ring terminal: Use ring terminal for M4</p>	<p>Allowable current for VCTF 3Cx 4 sqmm wires : 19.5A (at 40°C ambient) Notes : : Typical design assumes 40°C ambient temperature</p>
17 -1	General circuit breaker for AC incoming power wiring Recommended capacity for use (What you need to prepare)		<p><b>25A or 30A breaker for wiring (breaker ↔ charger)</b></p> <p>* Notes : : breaker capacity = breaker rated current x 80% &gt; load current. = 25A x 80%=20A &gt; Load peak current 18A -----</p> <p> <b>Caution: Do not use pig-nose (16A) sockets/plugs.</b></p> <p>* When using an outlet, we recommend using a European industrial socket/plug 3P (32A).</p>	<p>Pig-nose socket/plug (maximum current allowed is 16A):</p> <p>This 16A figure is possible under the best conditions, and older units can heat up quickly and be dangerous. For safety reasons, 10A or less is appropriate.</p> <p>* Safety standard: Outlet current is 8A or less.</p>
17	For AC incoming power wiring, install a ground fault circuit interrupter on the Recommended when using (What you need to prepare)		<p>We recommend the newest breakers available for converters. → aka "LS Electric SI Earth Leakage Circuit Breaker"</p> <p>( LS Electric / Model No. : <b>EBS52FB-SI 30A</b> ) , Explanation : <b>SI</b> = Super Immune (Earth leakage circuit breaker with high immune function) Cycle: For LS Electric products, we recommend products with the "SI" character, even if they have a different model number.</p> <p>When using a regular ground fault circuit interrupter, there may be malfunctions that cause unnecessary tripping, which is where the SI type ground fault interrupter above comes in. This ground fault interrupter is the latest generation of ground fault interrupters developed for converters, minimizing malfunctions. See the detailed documentation immediately below this table.</p>	

No	Item		Model Name : TC-3500W-50V60A	Remarks
18	AC Standby Power	RMS value	Standby current = 0.5A at 220V, where power factor = 6.6%, Standby Apparent Power = $V \times A = 110 \text{ VA}$ Standby Active Power = Standby Apparent Power x Power Factor = $110 \text{ VA} \times \text{Power Factor (6.6\%)} = 7 \text{ W}$	Standby active power = 7 W
19	Efficiency/Power Factor		EfficiencyMax. 91% , Power Factor Max. 98	At maximum output
20	Lithium batteries Protection		Output side short circuit protection / Charge over current protection / Charge over voltage protection / Charge reverse connection protection / Pre-charging function / *BMS/PCM unblocking function * BMS/PCM : Li-ion Battery Management System / Li-ion Battery Protection Circuit Module	
21	External temperature switch Connection controls	Add-ons (optional)	When charging the battery through the charging contactor, the contactor sometimes overheats. To prevent this, a thermoswitch (Normal Open Type) can be mounted on each of the contact electrodes (+)/(-) and connected in parallel to this connector. In this case, if the thermostat overheats and turns ON, the charger will stop charging and send an error signal.	
22	Safety features		* Charger self-protection in case of short circuit / * Battery overcharging and overcurrent charging protection / * Fault protection in case of reverse connection * Prevent power output from the output terminal when the battery is connected / * Stop charging when connecting a battery of another model	
23	Operating Temperature Conditions		Operating : $-20^{\circ}\text{C} \sim +40^{\circ}\text{C}$ / Storage : $-20^{\circ}\text{C} \sim +65$	
24	Size/Weight		W 107mm x H 227mm x L 462mm , 7.7Kg	



No	Item		Model Name : TC-3500W-50V60A	Remarks
24	External Control Communication Devices-1/2 (built-in)	Charge ON/OFF control and monitoring	<p><u>When set to auto-charge mode in the LCD monitor window, the communicator does not need to be used.</u>            Auto Charge mode allows the charger to automatically detect the battery and charge it when connected and cut off the output when the battery is removed.</p> <p>〈 When using a communication device</p> <p><b>Method (1) : DIO ( Digital Input / Output )</b>→ Molex Connector 8POS</p> <p><b>Method (2): RS485</b>→ DSUB 9Pin (Female, Female) connector / communication to adjust the charging voltage and charging current size,            Detailed error data is available.</p> <p>Cycle :            When connected to a DIO port, the DIO signal is automatically prioritized for charge control without any configuration.            When the DIO port and DSUB 9Pin connector are simultaneously connected, the DIO takes priority for charge control. However, the monitoring signal is sent to the DSUB 9Pin connector as well as the DIO.</p> <p>(See the separate communication protocols article. )</p>	
	External Control Communication Devices-2/2 (Customer purchases and applies a separate communication converter)	(Continued from previous)	<p><b>Method (3) : Blue Tooth Wireless Communication</b>→ Serial to Bluetooth Converter separately for RS485 port / DSUB 9Pin            (commercially available). See separate documentation for Tabos</p> <p><b>Method (4) : Ethernet (LAN) communication</b>→ Separate Serial to Ethernet Converter for RS485 port / DSUB 9Pin            (commercially available). See separate documentation for Tabos</p>	

No	Item		Model Name : TC-3500W-50V60A	Remarks
25	Optional products sold separately (Control panel switch)	Type : TWC-TX-STA-PNL	<p><b>(Configuration)</b></p> <ol style="list-style-type: none"> <li>1) Indicator light: green (charging), green blinking (full), yellow (standby), red (error)</li> <li>2) Selector switch: 2-speed / Standby &amp; Charge</li> <li>3) Pushbutton Switch: Error Reset</li> <li>4) Emergency switch: for emergency shutdown of the charger</li> </ol> <p><b>(install, run )</b></p> <ol style="list-style-type: none"> <li>1) Simply plug this product into the connectors (communication line and power) of the charger body. (Harness supplied)</li> <li>2) Power supply via AC220V power outlet</li> </ol> <p><b>(Advantages of this device)</b></p> <ol style="list-style-type: none"> <li>1) Interconnect the charger with the main control panel switches, and set the charger to Manual mode in the LCD setup window for convenient use without the need for any</li> </ol>	

## Cycle: Recommended ground fault circuit interrupters / Not required to use these

LS일렉트릭, 오동작 내성형 누전차단기 시장 니즈 맞춰 제품개발

누설전류 성분 알고리즘 적용, LED조명 등 비선형부하에 적합



LS일렉트릭이 홈 2상 전계 출시한 2차단기. 고조파와 제동성 서지(surge) 전류로 인한 기존 누전차단기의 오동작 문제를 해결한 제품이다. (제공:LS일렉트릭)

When using a regular ground fault circuit interrupter, there may be malfunctions that cause unnecessary tripping (depending on the site conditions), which is where the SI type ground fault interrupter comes in handy.

**LS Electric SI Earth Leakage Circuit Breaker→ Features : Enhanced harmonic immunity, enhanced overload current immunity**  
**Products with the letters "SI" in the model name. SI = Super Immune (Earth Leakage Circuit Breaker with High Immunity)**

This is a newly developed breaker for switched power supply (SMPS) loads. Tabos chargers are also a type of SMPS.


Type SI ground fault interrupters are equipped with a feature that prevents harmonics generated by the SMPS load from causing the ground fault interrupter to malfunction and trip (OFF).


A new type of ground fault circuit interrupter that has a microcomputer chip inside the breaker that monitors the power situation and only trips when it needs to.

LS Electric's SI circuit breaker can detect the fundamental wave component of the leakage current and distinguish the current that should be operated from the current that should not be operated, thus solving the malfunction problem.

Source: [electimes.com](http://electimes.com) Search terms: LS Electric SI circuit breaker

## 4. drawings





## **5. product features / safety features**

### **1) Self-protection function in case of short circuit:**

Short-circuit protection and auto-recovery: The output line will automatically detect a short circuit and cut off the output, and will auto-recover when the short circuit is terminated.

### **2) Prevent overcharging and overcurrent charging of the battery**

### **3) Primary and secondary isolation function:**

The primary AC power supply and the secondary output DC power supply are electrically isolated using a transformer.

This means that the primary power (AC220V) will not be transferred to the secondary side (battery charging) even if there is an internal failure, short circuit, fire, etc. of the charger. In other words, it is safe for charging lithium batteries because the battery will not be subjected to overvoltage due to internal failure of the charger.

(Note) :

When charging a lithium battery by connecting an uninsulated charger to the battery, if the battery (+) / (-) wires touch the ground (ground fault), the AC power breaker will usually trip. If there is no breaker or the breaker is overcapacity, the lithium battery may be damaged. (Battery hazardous conditions)

### **4) Reverse disconnect protection :**

The battery has a reverse polarity connection detector to prevent the battery and charger from failing when connected with the + / - reversed. A status indicator will appear on the LCD display and the user can correct the connection and charge normally.

### **5) Prevent power output from the battery output terminal:**

If there is no wire connection to the battery, no charging current will be output to the charger output terminals even if the charger is powered on.

### **6) Stop charging when connecting a battery from another device:**

For example, if a 25V battery is connected to a 50V charger, it thinks a heterogeneous battery is connected and will not charge it.

## 6. How to use General

### 6-1. LCD window display and inputs



- A. **[V/A SET] button** --> Max Charge Voltage, enter the maximum charge voltage.  
 \* The LCD monitor window displays the set value in the upper line and the actual value being charged in the lower line.
- B. **[ STATUS (ENTER) ] button** --> Checks the status of settings and errors and doubles as the 'Enter' button.
- C. **[Auto/Manual] button** --> What you need when not using the external control communication method.  
 \* Auto Mode: When the battery is connected, the charger automatically detects and starts charging.  
 \* Manual Mode : Press [CHG ON/OFF] button to charge or command charging using external control communication (DIO, RS485).
- D. **[COMM SET] button** --> Select external control communication method ( RS485 communication setting ).  
 \* If the DIO control is not set with the [COMM SET] button and only the DIO port is wired, the DIO control will be disabled.  
 DIO control automatically takes precedence and executes the command.  
 \* DIO controls take precedence over other controls.  
 For example, if RS485 command and DIO control are connected simultaneously, charge control is performed based on DIO command. However, monitoring information is provided simultaneously with DIO via RS485.
- E. **[CHG ON/OFF] button** --> Charging ON/OFF control when in Manual Mode (Manual Control)



## 6-2. How to charge the battery when it is overdischarged

### ( Forced-charging when a battery is over-discharged )



When charging a battery that has been shut off due to over-discharge, remove the load, connect the battery and charger 1:1, and use the Force Charge button on the LCD window. Press and hold for more than 4 seconds to enter Pre-charging mode to charge.

#### Caution:

In some cases, the battery may be damaged, and it can be dangerous to force charge it.

To avoid this issue, this force charge behavior should be performed with an operator watching from the sidelines.

If an abnormality is detected (battery making strange noises, smoke, etc.), charging should be stopped immediately.

When the battery is charged normally, it will automatically come out of forced charge mode and charge the battery in normal mode.

#### ◇ Force Charge Behavior Description :

##### (Models shipped after January 2024)

〈 charge 55 seconds at 5A, rest 5 seconds〉 / cycle→ Repeat this cycle 15 times. ( total time about 15 minutes ),

Raises an error if this behavior doesn't bring the battery back to life.

##### (Models shipped before December 2023)

〈 20 seconds charge at 5A, 5 seconds rest〉 / cycle→ Repeat this cycle 7 times. ( total time about 3 minutes ),


Raises an error if this behavior doesn't bring the battery back to life.

## 6-3. Enable Connector for Switch :

When shorted (ON), the charger is in normal operation; when open (OFF), the charger is shut down. This is for connecting an emergency stop switch, and

Normally, the charger must be left short-circuited (ON) to run.

#### Enable S/W Input



ENABLE 커넥터

상대물 (Opponent)



Phoenix 1827635  
3.81mm

## 6-4. External Thermal S/W Connector :

(Enable options / Use as needed)

When charging the battery through the charging contactor, the contactor sometimes overheats. To prevent this from happening, the contact electrodes (spring contact electrodes, contact shoes, wire connections, etc.

A thermostat (NO / Normal Open Type) can be fitted and connected in parallel to this connector.

When we talk about a thermostatic switch, we're talking about a switch that turns on when it reaches a certain temperature.

An unlimited number of thermostats installed in different heating locations can be paralleled and connected to this connector, each with a different operating temperature, as shown in the figure below.


If any of the multiple temperature switches are overheated and turned ON, the charger will stop charging and send an error signal.

These errors are cleared only by cycling the charger power.

### 외부 온도 스위치 ( External Thermal S/W ) Input

충전전선, 충전접촉전극, 배터리 등 발열이 예상되는 부위에 다수의 온도 스위치 부착 가능.  
추천예시 : 바이메탈 온도스위치 50도 ( Normal Open type )

Multiple temperature switches can be attached to areas where heat generation is expected, such as charging cables, charging contact electrodes, and batteries.  
ex) Bimetal thermal switch, 50 degrees celsius.



(Thermostat example): Key words: thermostat, bimetal thermostat,



## 6-5. Auto mode / Manual mode

### A) Auto Mode :



Use the Auto/Manual button in the LCD window to set it to Auto.

Once set, the mode is permanently memorized and not erased when the charger is powered off.

( Factory Default → AUTO Mode )

This mode automatically detects and turns the charge ON/OFF when the battery connector cable is removed without any charge instruction. If no battery is connected at this time, no voltage is output to the charger output terminal. (0V)

When using this charger for AMR (robot), AGV (automated guided vehicle), etc. to set up a charging station (docking method using contact electrodes)

Another option is to use the Auto Mode, which is a feature of this charger.

Auto Mode is set to Auto Mode using the 'Auto/ Manual' key on the switch on the charger's LCD window while the charger is always powered on. When the AMR or AGV arrives at the charging station and docks to the contact electrodes, the charger detects the battery voltage and automatically charges the battery. At this time, no electricity is sent to the charger output terminal in the standby state when the battery is not connected to the charger. (Output voltage 0V)

### B) Manual Mode :

Set to Manual mode using the Auto/Manual button on the LCD window.

Once set, the mode is permanently memorized and not erased when the charger is powered off.


Connect the battery to the charger output and press the charge (CHG) button on the LCD window or send a charge command to the communication port DIO or RS485 to charge the battery.

Operation sequence:

Dock to robot (AMR, AGV) charging station --> Command charger to charge ON --> (Perform charging action)

--> tell the charger to charge OFF --> the charger sends the robot a signal to stop charging and shut down

--> Return charging station electrodes and depart robot




Status display at the top of the LCD window : MAN.

(Manual) / AUTO

## 6-6. Parallel Operation :

You can run up to four of these chargers in parallel if you want to increase the charging current. One charger is set as Master, and the other 1-3 are set as Slaves.



Connect the chargers to each other with separate RJ45 connector wires and set the number of parallel runs by turning the rotary switch next to them. Once the RJ45 connectors are properly connected, the LCD window will automatically display Master and Slave.

When running in parallel, you do not need to make any settings in the LCD window. However, you only need to set the total output current on the charger that is set as Master.

(Example) : Max. 60A when 3 in parallel \* 3 units = Max. 180A

If you run 3 in parallel, but the current set by the Master is 100A, then each charger will put out 33A, which is 1/3 of the value.


**⚠ Note:** The battery connection wires (DC output wires) must each be the same thickness and the same length.

### 6-6-1. Parallel Drive Wiring and Operation

\*Note: DC output (charging) wire thickness selection criteria for parallel operation → Apply 3A per 1sqmm wire thickness → 3A/sqmm, which is a sufficient size to avoid voltage drop across the wire.

(Example 1) : For 2-parallel operation →  $60\text{A/pcs} \times 2\text{-parallel} = 120\text{A}$  , final output wire thickness =  $120\text{A}/(3\sim 4\text{A/sqmm}) = 35\text{sqmm}$  wire → 2-parallel wire joining part is recommended to use busbar.

(Example 2) : For 4 parallel operation →  $60\text{A/pcs} \times 4\text{ parallel} = 240\text{A}$  , final output wire thickness =  $240\text{A}/(3\sim 4\text{A/sqmm}) = 70\text{sqmm}$  wire → In this case, use busbar.





## 6-6-2. Understanding the 'COM\_SET' button of the LCD monitoring window for parallel operation

The parallel drive is using CAN communication mode.

However, there is no special 'COM\_SET' to be set by the user when running in parallel.

The following is a reminder



Press the 'COM\_SET' button and you will see the screen on the left.

When it comes to parallelism, the only settings the user can change are the  
CAN RT : <Terminal resistance ON/OFF setting for charger parallel operation

For the last charger set as a slave, it can also be set to CAN RT:ON.

However, general parallelism is not possible with  
In this case, the communication line (RJ45 jack) connecting the charger to each other has a short ground pole, so there is no problem even if CAN RT : OFF is set.

Note that the

RT / Resistor Termination is the last end of the cable, which sometimes causes poor communication due to echo phenomenon when parallel communication is performed.

In this case, the last charger on the cable turns on the termination resistor to eliminate poor communication due to echo.

If the length of the communication cable is short (1~2m), leaving the termination resistance (RT) OFF will not cause communication failure.




## 7. settings and external control methods

### 7-1. External Control Using DIO / Digital Input Output

When this DIO connector is connected, DIO control is automatically prioritized and operated without any setting (no need to set it in the LCD monitor's menu).

#### CTL IN / OUT ( Manual mode )

본 DIO 커넥터와 RS485를 동시에 사용하지 마십시오.



INPUT POWER는 필터 기능이 내장된 절연형 컨버터를 통과한 전원 사용을 권장합니다.

외부제어(DIO/RS485)시에는 LCD 설정창에서 'AUTO' 모드에서 'MANUAL' 모드로 변경시켜야합니다.

For INPUT POWER, it is recommended to use power that has passed through an insulated converter.

In the case of external control (DIO/RS485), you need to change it to 'Manual' mode via the LCD setting.

\* Cycle 1: If you want to use DIO and RS485 simultaneously, you can do the following.

< DIO communication --> command and monitoring, RS485 communication --> use only monitoring >.

\* Cycle 2: When used, the DIO OutPut signal outputType can be changed by the consumer in the setting window as shown below.

This charger's LCD window / Setting menu / DIO OUTPUT Type / 'NORMAL' Type and 'REVERSE' Type

You can select it as a Type.

The default mode is NORMAL' Type.

The output signal (High / Low) level is inverted compared to the NORMAL type, which is called REVERSE type: .

NORMAL' Type : Input signal corresponding to ON signal becomes Low, output signal becomes High


**REVERSE' Type : Input signal corresponding to ON signal becomes High,  
output signal becomes Low**

See the schematic below (CASE 1)

(1) Basic structure of the Out Put circuit of DIO (Digital Input / Output) circuit→ Open Collector method

**This is done by attaching a pull up resistor on the user's side. (See figure below.)**

**\*Output / Monitoring:** If pins 5 through 8 and pin 1 '(-)Common' are floating, the corresponding signal is output.



(2) Caution when using DIO output line

Pins 5,6,7,8 Output are signal wires and are used to check high/low, not to consume power.  
The maximum allowable current for this output signal wire is 40 mA, recommended 25 mA.

If more than this current is drawn, the DIO circuitry inside the charger will burn out or become unusable.



Therefore, this signal cannot be used to directly drive a magnetic relay (coil type) or directly drive a high-power LED.

If you want to attach a relay to this signal line, we recommend a FET or SCR (Silcon Controlled Rectifier) that can drive low current. Make sure that the gate drive current is 25 mA or less.

Also, if you want to attach a signal LED, you can usually use 10mA or less for signal LEDs with a diameter of 5mm or less, but you need to make sure that it is within the allowable current.

### (3) Analyze DIO Output Line Use Cases

If you want to drive large power using the DIO output lines, you can do so in the following ways.



See "When using the (CASE3) SSR" above for precautions and tips:

\*If you configure the SSR (Semiconductor Relay) circuit as shown above, you need to change the DIO output type to the following.

→ This charger's LCD window / Setting menu / DIO OUTPUT Type / 'NORMAL' Type → 'REVERSE'

You need to replace it with Type.

An action to reverse inverted input and output signal levels.

\*Recommended SSR (Semiconductor Relay) : Model S4T-16P-202D / 4-channel type / Ring terminal type

#### (4) Type / Command

When pin 3 and pin 1 '(-)Common' are short-circuited (closed), this is the command to start charging.

Reset sign is entered when pin 4 and pin 1 '(-)Common' are short-circuited (Closed)

(i.e., an ON signal is input when a conductive state is made between the input terminal and pin 1 '(-)Common' terminal.)

If an error occurs and the error reset command fails to cancel, first check the error on the LCD monitor and take action.

In some cases, you may need to turn the ENALE terminal (or power switch) off and then back on again.

## 7-2. Control by connecting to the control panel (option product) using DIO --> Refer to Contents / How to connect to the control panel

## 7-3. External Control via RS485 Communication / Using D-SUB 9Pin Connector

〈 See separate document for RS485 communication protocol. 〉

### 7-3-1. Cautions

When a D-SUB 9Pin connector is connected, D-SUB 9Pin control is automatically activated without any setting.

RS485 communication (D-SUB 9Pin) and DIO communication can be used simultaneously.  
However, it can be confusing to issue both charge and end charge commands at the same time, so it works as follows.

If the command to start charging is sent to the DIO, the command to end charging must be sent to the DIO.

(In this case, RS485 communication is only monitored; it does not listen to the end-of-charge command via RS485 communication).

And then

If the next charge is commanded with an RS485 command rather than a DIO command, the RS485 will be prioritized and the charge will start. The end of charge command must be issued via RS485.

(In this case, DIO communication is only monitored; it is not listened to when a command to end charging is issued over DIO communication.)

### 7-3-2. Example of using RS485 communication (D-SUB 9Pin) and DIO communication at the same time

If you want to use DIO and RS485 communication together, you can use the following example.

(case 1) :

Command DIO to start and stop charging.

RS485 communication is for monitoring only.


(case 2) :

Issue commands to start and stop charging via RS485. Monitor at the same time.

The DIO communication can also be used for status indicator monitoring, for example, to attach a separate LED signal lamp (or warning light).

### 7-3-3. RS485 Communication (D-SUB 9Pin) Pin Map

RS485 PIN MAP		
핀번호	이름	설명
1	Vcc	+5V / 통신전원
7	DATA+	RS-485 POSTIVE
3	DATA-	RS-485 NEGATIVE
4,5	GND	GROUND



#### 7-3-4. Understanding the 'COM\_SET' button of LCD monitoring window to use external control RS485 communication

When the user controls this charger externally (RS485 communication), the settings on the monitor below are set to

You only need to set the RS485 ID and RS485 RT (termination resistance).

Note: CAN communication mode is only used for parallel operation of the charger.

This feature is not available to users for communication control.



Press the 'COM\_SET' button and you will see the screen on the left.

The only settings that a user can change are the RS485 ID : <Address setting, 1,2, etc...> RS485 ID : <Address setting, 1,2, etc...> RS485 RT : <Termination resistance ON/OFF setting when controlling external communication of charger>.

< Below is for parallel operation of charger >.  
CAN RT : <Terminal resistance ON/OFF setting for charger parallel operation> <Terminal resistance ON/OFF setting for charger parallel operation>

Note that the

RT / Resistor Termination is the last end of the cable, which sometimes causes poor communication due to echo phenomenon when parallel communication is performed.

In this case, the last charger on the cable turns on the termination resistor to eliminate poor communication due to echo.

If the length of the communication cable is short (1~2m), leaving the termination resistance (RT) OFF will not cause communication failure.

**Note :**

Blue Tooth wireless and LAN communication methods are described later.

## 8. error and status messages

(The error list below is output to→ and displayed on the LCD as well.)

\* Periodicity: Error auto-clear condition: When battery is removed or when error condition is cleared

Separation	Communication Code	LCD display text	Contents	Cause/Action	ErrorsAuto Off	Remarks
Behavior Bad	0	OUT CURRENT OVER	Output Current Overrun Error	80A or more detected / professional inspection and replacement required	X	
	1	out voltage over	Output Voltage Overrun Error	86V or higher detected / professional inspection and replacement required	X	
	2	CHG TEMP OVER	Internal Main Power Board Temperature High Error	When detecting above 60 degrees / bad temperature sensor or high operating environment temperature	X	
	3	pfc current ovdr	Input Current Error	Needs inspection and replacement	X	Detect 20A or more at 380V
	4	pfc voltage over	Input Voltage Error	Needs inspection and replacement	X	Detect 450V or higher
	5	PFC TEMP OVER	Internal Power Factor Correction Circuit (PFC) High Temperature Error	When detecting above 60 degrees / bad temperature sensor or high operating environment temperature	X	
External Bimetallic	6	ext. temp-h/stop	External Bimetal (Contact) Behavior Notification Error	External bimetal health check action required / <u>must power reset.</u>	X	<u>If the error still occurs after power reset, remove the bimetal temperature sensor and check the cause</u>



Separation	Communication Code	LCD display text	Contents	Cause/Action	ErrorsAuto Off	Remarks
Failed charge	7	OUT current ZERO	Charge Current Not Output Error	Battery voltage recognized, but current disturbance error. Final error after 5 retries (after 5 seconds of inactivity) / error automatically cleared when battery is removed.	0	
Failed charge	8	(not used)	-.	-.	-.	-.
Failed charge	9	BAT OVER VOLT	Overvoltage error at start of charge	Check voltage between Ready → Normal-CHG for errors higher than 58.8V / Auto dismiss errors when battery is removed.	0	
Failed charge	10	BAT UNDR VOLT	Low voltage error at start of charge	Check voltage between Ready → Normal-CHG for errors lower than 40.6V / Auto disable errors when battery is removed.	0	
Failed charge	11	BAT REVERSE	Battery (+) / (-) reverse connection status error	Check for reverse connections	0	The circuit is present, but the error indication is inactive. <u>Currently, in firmware 1.06, the battery does not charge when connected in reverse. No error display. (Works since 2024.09)</u>
Failed to start	12	Calibration ERR	Calibration errors	Sequence required at startup. Check/replace required if error occurs	X	

Separation	Communication Code	LCD display text	Contents	Cause/Action	ErrorsAuto Off	Remarks
Failed to start	13	PFC Voltage LOW	Power Factor Correction Circuit (PFC) Low Voltage Error on Charger Power Up	Sequence required at startup. Check/replace required if error occurs	X	
Failed to start	14	UIboard COM OPEN	User Communication Board Errors	Sequence required at startup. Check/replace required if error occurs	X	
Parallelism	15	Parallel CH CHK	CAN communication address conflict error in parallel operation	Need to check communication address settings when running in parallel.	X	
Display Bad	-	LCD Data Line ER **Check Device**	LCD display device anomalies (affected by noise, surge, etc.)	Display unit only. No separate communication cord. Power reset or LCD check/replacement required. display shows error, but no error in actual communication.	→	Automatic error cleared for normal LCD operation.


## 11. Add an external control method

〈 This document applies to both the 3500W corded and wireless charger.

### 11-1. Blue Tooth Wireless Communication






- \* Cycle 1: User purchases and uses a commercially available Serial to Bluetooth Converter.
- \* Cycle 2: RS485 to wireless communication (Blue Tooth) converters are available from several manufacturers,

Tabos tried out the chipsen.com product (below) and found it to be a good fit.



〈 Figure 3500W Charger Wireless Communication Module Mounting Space

## 11-1-1. Preparation

	Manufacturer name	Type number	Product description	Remarks / Uses
<b>λ</b> Essentials (Purchased by user)	Wireless RS422/485 Serial converters (adapters) 	RCPORT-TD450 < chipsen.com >	* Connection: D-Sub9-pin ( Male / Male ) * Protruding length after connection: about 100mm * 1:1 node switching to 1:7 <div> * Tabos charger (wireless charger included) D-Sub9 pin (female/female) communication wire and 5V power wire pinmap are completely matched, </div>	* Connect to the charger
<b>B</b> Essentials (Purchased by user)	Wireless RS232 to USB converter (adapter) 	RCPORT-TD420 < chipsen.com >	* Connection: USB plug, * Length after connection: approx. 90mm * 1:1 node switching to 1:7 multicommunication (up to 7 multicommunications)	* Connect to Host (PC)
Below is a tool for working with the RCPORT-TD450 converter (adapter) by connecting it to a PC to ① change the communication speed and ② pair it.				
<b>③ â</b> Supplies (Purchased by user)	USB Male to 485 Terminal 	3pin or 5pin type is irrelevant	There are several shapes. It doesn't matter what it looks like.	* Connect to your PC
<b>④ â</b> Supplies (Purchased by user)	DSUB9 Female to Terminal 		There are several shapes. It doesn't matter what it looks like.	* Wireless RS422/485 Serial Converter (Adapter)  RCPORT-TD450 Connect to
<b>⑤ â</b> Supplies (Purchased by user)	Wire 3core, AWG24 or AWG22 	(Example: UL2464, 3Core, 22awg wire)  Length: about 30 cm or more		* For connecting parts 3 and 4

## 11-1-2. Installation Methods and Process

### ( Step 0 ) : Consider mechanical design when applying wireless modules

If the Blue Tooth module (wireless converter (adapter)) is surrounded by a conductor, such as a metal enclosure, radio waves will not go out.

Be careful with your choice of reference material. It does not matter if it is surrounded by non-conductors (plastic, ceramic, etc.).

If you're completely encased in metal conductors and can't communicate, use the



You can use a commercially available "Bluetooth module extension cable" to move the antenna out of the way.

### ( Step 1 ) :


Go to the manufacturer's website at [chipsen / chipsen.com](http://chipsen.com) and familiarize yourself with the user manual for your model.

These are the minimum precautions for connecting to a Tabos charger.

(Step 2) : Change the baud rate of the 'RCPORT-TD450' serial converter (adapter) attached to the charger to **19200**.

**Step2-1)** Download the 'RCPORT-TD450' MANAGER program from [chipsen.com](http://chipsen.com) and install it on your PC.

**Step2-2)** Align the selection switches as shown below.




〈 Pictured above: Connecting to the charger 〉.

**Step2-3)** Connect the 'RCPORT-TD450' with your PC using a 'USB to 485 adapter'.

〈 Connect to a PC using accessories ③, ④, and ⑤ above 〉.

When finalizing, use the following as a guide to finalizing

3-3. "USB to 485 터미널" 전선 연결--> RS485통신은 아래와 같이 2선식 및 4선식이 있습니다.



**Step2-4)** After executing 'RCPORT-TD450' MANAGER, if it connects to PC normally, click  
You should see a screen like the one below.

**Make sure to set the communication rate to 19200.**

**RCPORT-TD450 Manager**

**[ 장치 정보 ]**

블루투스 주소: 5CF28646C1AD    펌웨어 버전: v1.0.0

장치 이름: TD450    이름 변경    Advertising 간격: 500 msec    저장

정보 갱신    장치 재시작    공장 초기화

**[ UART 선택 사항 ]**

통신 속도: 19200    패리티: None    스탑비트: 1    적용

RS485 에코 모드: Off    중단 저항: Off

**[ 장치 등록 (Master 기능) ]**

장치 검색

☐ 장치명 필터: CHIPSEN    검색

☐ RSSI 필터: -45

장치 주소	장치 이름	RSSI

등록 장치 목록

블루투스 주소


=> 1			X
=> 2			X
=> 3			X
=> 4			X
=> 5			X
=> 6			X
=> 7			X

저장

COM8    Version 1.0.2



**( Step 3 ) : 1:1 pairing and communication speed settings**



**\* RCPORT-TD450' as shown in the photo above,**

- Set the rotary switch to 'Set'.
- Set the Set Device Number rotary switch to '1'.
- Set the sliding select switch to 'S', or Slave.
- Apply power to the unit.

**\* RCPORT-TD420' (attached to the HOST or PC) as shown in the photo above,**

- Set the rotary switch to '19.2K'.
- Set the Set Device Number rotary switch to '1'.
- Set the sliding select switch to 'M', or Master.
- Connect to a PC. Or power the unit.

**\* The pairing is complete when the green signal lamp is continuously lit on both sides of the device.  
However, if the green lamp is blinking, pairing is not successful.**

**\* See the .chipsen.com homepage specification for more detailed usage.**

**( Step 4 ) : Enable communication**

- \* Following the above steps  
Change the rotary switch on the RCPORT-TD450 from 'Set' to '485'.

**( Step 5 ) : 1: Multiple pairing Refer to the specification sheet on the→ .chipsen.com homepage.**

## 11-2. Ethernet (LAN) Communication Module

〈 This document applies to both the 3500W corded and wireless charger.


**\* Recommended products** ← prepared by the user

Name: sLANall RS485 to LAN Serial Converter Basic

Type name: sLANall

Manufacturer: SystemBase, Inc. / [sysbas.com](http://sysbas.com)

How to use: See manufacturer's website



### 〈 Caveats

Normally, you don't need to set a terminating resistor if the communication distance is short.

Through our own testing, we have found that the communication quality of this communication conversion adapter depends on whether or not the termination resistor is set.

Important: Set the termination resistance (RT) during RS485 communication setup in the LCD window of the Tabos charger.

## 21. Charger Control Panel (optional) specifications/drawings and usage

### 21-1. The Need and Role of the Control Panel



You can check the charging status through the indicator light (Standby, Charging, End of charge, Error).

**The emergency switch can be used when you want to stop charging immediately, including in case of emergency (smoke, fire, etc.).**

**Note that most battery fires occur while charging.**

- ③ There is a spare connector for the user to attach an additional DC fan (the fan is only powered during charging).
- ④ There is a port for the user to mount an additional proximity sensor to check if the AMR has arrived at the charging station. When the sensor detects that the AMR has arrived at the charging station, the control panel automatically issues a command to start charging.

〈For wireless chargers only: below〉.


In this case, no charging command is given to the faucet controller, and the faucet controller becomes a passive slave.

☎ Contact Tabos if you need this approach. There are additional steps you can take

### 21-2. Photos and drawings



〈 Control Panel Drawing 〉



### 21-3. Control Panel Functions

And on the control panel

1) Start/stop charging can be commanded with the selector switch (rotary switch).

When configuring as a charging station for robots (AMR, AGV)

When the selector switch is placed in the ON position, the robot arrives at the charging station and contacts the battery charging terminals (charge contactors).

The charger automatically detects the battery connection and charges it automatically.

If the charging terminal falls off, it stops charging and does not output electricity to the charging terminal (as a safety measure).

2) Error reset can be done with a pushbutton switch.

3) You can make an emergency stop with the emergency switch.

4) A multi-colored LED lamp indicates status.

Green: charging / Green blinking: full / Yellow: waiting to charge / Red: error status

5) Buzzer: There's a switch next to the error tone/buzzer that you can turn off if it's too loud.

6) Additional Features ① : There are two Molex connectors that can drive two DC24V FANs.

Use: If you are building this charger enclosure and installing only this control panel on top of it, Fans can be run for internal ventilation of the enclosure.

This FAN will run when the charger is operational and for a period of time after the charger is shut down for additional cooling.

7) Additional Function ② : Allows you to connect the sensor to the main control panel.

The way it works is that the connected sensors detect the arrival of a robot (AMR) that wants to charge and use this signal to instruct the charger to charge.

When applied to a wired charger, it works in Manual Mode. / Does not work in Auto Mode.

When applied to a wireless charger (WPT), it works in Remote. . / Does not work in Local Mode.

The following applies to wireless chargers only-----

(Note when applying to wireless chargers)

Special care must be taken when connecting the arrival detection sensor of the driving robot light to the wireless charger (WPT).

This is because the electromagnetic waves emitted by the TX coil pad may affect the sensor, causing malfunction or damage to the sensor. Therefore, if you plan to use this sensor, please contact Tapos for technical consultation.

\*Example: Type of sensor available (magnetically shielded type required) and distance from TX coilpad, Consulting on how to block TX Coilpad electromagnetic interference.

-----

## 21-4. (Optional Product) Control Panel Specification List

Tabos Development / Direct Production

( Made in Korea )

No	Item		Model Name : TWC-TX-STA-PNL	Remarks
1	Authentication	Replaced by <b>CB, CE,</b> and <b>UL</b> certifications of the applied AC/DC converter.	Equipped with a 15W output converter that converts AC220V to DC12V.  ACDC Converter Model : RS-15-24 / <b>CE, CB 및 UL</b> Cetified	
2	Purpose	Applicable devices	(1) Tabos Wireless Charger Transmission Controller (TWC-2500W-A-TXCOIL) (2) Tabos Wired Charger ( TC-3500W-□□□□ ) (3) Tabos Wired Charger ( TC-7000W-□□□□ )	Connected to a battery charger Perform charge command and monitoring functions
3	Input power specifications	RMS value	<b>Single-phase 110 VAC to 240 VAC / 50 to 60 Hz, current 0.1 A at AC220 V</b> Connector: Pigtail Plug	
4	System Power		<b>DC 24V (powers all sensors, switches, alarms, and external FANs)</b>	Isolated Converter / OutPut :24V 15W, 0.625A
5	Accessory wire length	Length (m)	① Enable wire and DIO wire→ 0.96 meters each. ② AC power input pigtail cable→ 1.7 meters or more	Secure the wire bundle with cable ties from the clear back cover to the The length measured from the point of tying
6	Size and weight	mm, Kg	(L) 340 x (W) 160 x (H) 160 mm (excluding cable dimensions), Weight: 1.5 Kg (with cable)	
7	Switch	Emergency switch	Charger Emergency Stop / *Cycle: Emergency stop charging, but not the FANs can run in emergency shutdown conditions. No polarity.	If the emergency switch is set to Directly connected to the Enable switch.
8		Buzzer switch	Enable buzzer notification sound (ON/OFF control)	Switches with direct hardware connection to the light
9		Rotary direct switches	Charging ON / OFF	Operation via Digital I/O (DIO) signals

No	Item		Model Name : TWC-TX-STA-PNL	Remarks
10		Pushbutton switches	Clear errors	
11	Warning lights (Content by color)	Tri-color LED (red, amber, green)	<b>Red: Error / Yellow: Standby / Green: Charging / Green Blink: Full</b>	
12	For users Spare connectors	<b>FAN drive connector ( 2 )</b>	<b>For DC24V FAN drive, ( 0.15A/channel ) x 2 channels</b> (Runs when charging, and runs for an additional 5 minutes when charging ends) 2POS Connectors ( 1 +, 2 - ) , Molex 3515502	Something that users can use as needed. The additional uptime after charging ends is Subject to change and adjustment without notice.
13		<b>Connectors for charge command sensors ( 1 )</b>	Users can mount sensors to use this signal to command charging ON/OFF. <b>Available Sensor : DC24V Power, PNP Type / N.O. Type</b> 3POS connector (1 SIG, 2 24V, 3 GND) , Molex 05110303	When using this control panel for a charging system that charges a mobile robot, it can be used to detect if the mobile robot has arrived at the correct location. When the sensor is detected, a charge ON command is issued.

## 21-5. Wiring Method Details

The cable that comes with the Tabos add-on like the one pictured below is attached to this charger's

- 1) DIO connector (for charging commands and lighting the charge status signal lamp) and
- 2) Plug it into the Enable connector (for the emergency switch),
- 3) Plug in the AC220V (0.15A current draw) pigtail power connector.



## 〈 Wiring Diagram


### TWC-TX-STA-PNL

( 실물 사진 및 결선 방법 )

2023.11.27

#### 출력 전선

- 1) AC220V 돼지코 플러그 / 0.1A ,
- 2) DIO (Digital Input Output) 전선 코넥터 <---> 충전기(또는 WPT\_송전제어기) 본체의 DIO 코넥터와 접속
- 3) Enable 전선 <---> 충전기(또는 WPT\_송전제어기) 본체의 Enable 코넥터 (나사식 단자)에 접속



#### ( 결선 방법 )

Enable 코넥터  
( 비상스위치에 연결됨 )


DIO 코넥터



< 타보스 무선충전기 송전제어기 >  
TWC-2500W-A-TXCTL

Enable 코넥터  
( 비상스위치에 연결됨 )

DIO 코넥터



< 타보스 유충전기 / TC-3500W 시리즈 >

Enable 코넥터  
( 비상스위치에 연결됨 )



DIO 코넥터




< 타보스 유충전기 / TC-7000W 시리즈 >

## 21-6. Spare connector details for user (FAN drive, charge command sensor)

- 1) Fan1, Fan2 drive connector: This connector is powered only during charging, but after the charge expires, it is powered for an additional period of time to increase cooling performance.
- 2) J19 connector: Sensor connector required when the robot (AGV, AMR) detects that the robot has arrived at the charging station and uses this signal as a charging command signal (Normal Open type PNP sensor can be installed)



## 21-7. How to set the LCD window for operating this control panel



For wired chargers [or wireless chargers], click the  
Use the Auto/Manual button to set it to Manual.

(However, if you are in Auto mode instead of Manual mode, you can only monitor, but the alarm will still work).